

# Sofia

MADAME PARIS

## BROSSE LISSANTE

### FONCTIONS

1. Bouton d'allumage
2. Température +
3. Température -
4. Ecran LCD
5. Température
6. Timer
7. Fonction ionique
8. Indicateur Celsius/ Fahrenheit



### CARACTÉRISTIQUES

Dimensions : 27.0 x 7.5 x 7.8 cm

Poids : 396 g

Voltage : 100 - 240V

Puissance : 65W

### COMMENT UTILISER LES BOUTONS?

- Brancher la brosse. L'écran LCD clignote "OFF" en bleu et blanc. Appuyer sur le bouton d'allumage pendant 3 secondes pour allumer ou éteindre la brosse.
- Note:** En veille, le mot "OFF" clignote indéfiniment, il est recommandé de débrancher la brosse.
- Par défaut la température de la brosse est de 180°C. Pour ajuster la température utiliser les boutons "+" et "-". Chaque pression augmente ou diminue la température 1°C, en appuyant sur le bouton plus longtemps la température variera plus vite.
- Après avoir choisi la température, l'écran LCD est bleu avant de s'éclairer en blanc une fois la température atteinte. La jauge sur le côté gauche de l'écran indique que la brosse est en train de chauffer et si la température choisie est plus ou moins élevée.

### FONCTIONS SPÉCIALES

- Après 3 secondes sans toucher les boutons, la brosse se bloque, la mention "LOC" apparaît sur l'écran. Pour débloquer la brosse, appuyer deux fois de suite sur le bouton d'allumage.
- Pour passer des degrés Celsius aux degrés Fahrenheit, appuyer sur les boutons "+" et "-" simultanément.
- Pour activer la fonction ionique, appuyer deux fois sur le bouton d'allumage. Un symbole "Ion" apparaît sur l'écran LCD. Pour désactiver les ions il faut appuyer trois fois sur le bouton d'allumage
- Après 30 minutes, la brosse s'éteint automatiquement. Pour régler le timer, il faut appuyer une fois sur le bouton d'allumage et ensuite régler la durée avec les boutons "+" et "-".

### COMMENT UTILISER LA BROSSE?

#### Température

Cheveux épais et denses : 190 à 230°C

Cheveux normaux : 160 à 190°C

Cheveux fins : 120 à 160°C

Utiliser la brosse sur cheveux propres, secs et démêlés. Séparer vos cheveux en différentes mèches avant de passer la brosse doucement de la racine vers les pointes, en passant aussi bien au dessus qu'au dessous de la mèche.

Pour un meilleur lissage, faire en sorte de garder la mèche tendue dans la brosse avec votre main libre.

MADAME PARIS

[www.madameparis.fr](http://www.madameparis.fr)  
[facebook.com/madameparis75](https://facebook.com/madameparis75)  
[contactmadameparis@gmail.com](mailto:contactmadameparis@gmail.com)

## PRÉCAUTIONS D'EMPLOI

1. Ne pas toucher les picots de la brosse lorsque celle ci est allumée sous risque de brûlure.
2. Ne pas utiliser la brosse dans la baignoire ou sous la douche.
3. Tenir éloignée des points d'eau. Débrancher immédiatement la brosse si elle est au contact de l'eau. Ne pas toucher la brosse.
4. Toujours vérifier l'état du câble électrique avant d'utiliser la brosse.
5. Attendre que la brosse refroidisse avant de la ranger
6. Ne pas laisser à la portée des enfants.
7. Ne pas utiliser la brosse si elle est endommagée

## PRODUCT DIAGRAM

- 1.Power Button
- 2.Temperature +
- 3.Temperature -
- 4.LCD Display
- 5.Temperature
- 6.Timer
- 7.Ion Function
- 8.Celsius / Fahrenheit Indicator



## SPECIFICATIONS

Dimensions : 27.0 x 7.5 x 7.8 cm  
Weight : 396 g  
Voltage : 100 - 240V  
Power : 65W

## HOW TO USE THE BUTTONS

- Connect the brush to a power source and it will be on standby mode with the LCD blinking "OFF" in an alternating blue and white light. Press and hold the Power Button for 3 seconds to turn on / off the brush.
- **Note:** In standby mode, the LCD will always blink "OFF". It is recommended to unplug the brush once you are finished using it.
- The initial temperature is set at 355°F. Adjust the temperature by pressing the Temperature + / - Button. Each press will change the temperature by 2°F. You can also press and hold the Temperature + / - Button for 3 seconds to continuously increase / decrease the temperature.
- After the temperature setting is done, the brush will go through a temperature adjustment process and the LCD will light up blue. On the LCD screen, the heating process and the current temperature are clearly shown. When done, the LCD will turn white.

## SPECIAL FEATURES

- The temperature control automatically locks after 3 seconds to prevent accidentally pressing the wrong button. A "LOC" reminder will be shown on the LCD when a button is pressed. Double press the Power Button to unlock.
- Press the "Temperature +" and "Temperature -" button at the same time to switch between Celsius and Fahrenheit.
- Activate the ion function by pressing the Power Button once. The LCD will show "Ion" once this function is turned on. It removes static electricity to protect your hair from damage and make it smoother. Press the Power button three times to switch off the ion function.
- You can also set a timer by pressing the Power Button once. Adjust the auto shutoff timer from 30 minutes to 120 minutes through the "+" and "-" Button. When no timer is set, the brush automatically powers off when turned on for 30 minutes.

## HOW TO USE THE BRUSH ?

### Temperature

Thick / dense hair: 380 to 450°F  
Medium volume hair: 320 to 380°F  
Soft / fine hair: 250 to 320°F.

1. Make sure your hair is clean, dry and combed. Separate your hair into small strands before using the brush from roots to ends. You can use it above and under the strands for a better effect.
2. Pull and hold your hair with one hand and gently brush it with the brush in your other hand.

The brush part is thermal conductive and becomes hot during use. Please only hold the handle and be careful not to get burned.

## CAUTION

1. The brush part is thermal conductive and becomes hot during use. Please only hold the handle and be careful not to get burned.
2. Do not use this product in a bathtub, in the shower, or anywhere with dripping water.
3. Keep away from water. In case it comes in contact with water or falls into water, please immediately unplug the power. Do not touch the product with your hands.
4. Make sure the power cable is intact. Stop using if you notice a ruptured wire.
5. Wait for the brush to cool off before storing.
6. Not a toy. Keep away from children.
7. Do not smash or drop the product. Stop using if damaged.